

To Retrieve Data of Successful and Failure Photo Capture from FingerTec i-Kiosk 100 Plus Terminal

Below is the function calls to retrieve the successful photo capture data and failure photo capture data from FingerTec's i-Kiosk 100 plus terminal.

```
VARIANT_BOOL GetFailPhotos([in]BSTR FilePath, [in,out]BSTR *FileName)
```

FilePath = File path name to store the photo

FileName = photo file name, separated by "&"

Return: 1-success, 0-fail

```
VARIANT_BOOL GetSuccessPhotos([in]BSTR FilePath, [in,out]BSTR *FileName)
```

FilePath = File path name to store the photo

FileName = photo file name, separated by "&"

Return:1-success, 0-fail

Sample:

```
Dim FilePath As String
```

```
Dim filename As String
```

```
Dim filep As String * 40960
```

```
If BioBridgeSDK.GetFailPhotos(FilePath, filep) Then
```

```
    Dim length, start, endc As Integer
```

```
    start = 1
```

```
    length = 0
```

```
    endc = InStr(start, filep, "&")
```

```
    length = endc - start
```

```
    Do While endc
```

```
        filename = Mid(filep, start, length)
```

```
        List1.AddItem (filename)
```

```
        start = endc + 1
```

```
        endc = InStr(start, filep, "&")
```

```
        length = endc - start
```

```
    Loop
```

```
    MsgBox (" download fail picture success ")
```

```
Else
```

```
MsgBox (" download fail picture failed ")
```

```
End If
```